MAX-S520/S530GB latin-1~14 2/13/03 8:54 Page 1

SAMSUNG

THREE-CD CHANGER MINI-COMPACT SYSTEM

CD-R/RW PLAYBACK

MAX-S520
MAX-S530

Instruction Manual



Safety Warnings

GB

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT
PRODUCTO LASER CLASE 1


CAUTION
RISK OF ELECTRIC SHOCK.
DO NOT OPEN
CAUTION:
TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE REAR COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.

Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION-INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.

This symbol indicates that dangerous voltage which can cause electric shock is present inside this unit.

This symbol alerts you to important operating and maintenance instructions accompanying the unit.

WARNING: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

Contents

Thank you for buying this SAMSUNG mini-compact system.

Please take time to read these instructions. They will allow you to operate your system with ease and take full advantage of its features.

GB

♦ SAFETY WARNINGS 2
♦ INSTALLING YOUR MINI-COMPACT SYSTEM
■ Front Panel View 4
■ Remote Control 5
■ Rear Panel View 6
■ Where to Install Your Mini-Compact System 7
■ Connecting the Loudspeakers 7
■ Inserting Remote Control Batteries 7
■ Connecting the AM (MW/LW) Aerial 8
■ Connecting the FM Aerial 8
■ Connecting your System to the Power Supply 9
■ Demo/Dimmer function 9
■ Setting the Clock 9

♦ CD-PLAYER
■ Loading and Changing Compact Discs 10
■ Listening to a Compact Disc 10
■ Selecting a CD in the Disc changer 11
■ Selecting a Track 11
■ Searching for a Specific Music Passage on a CD 11
■ Shuffle Play Function 11
■ Repeating One or All Tracks on the Compact Discs 12
■ Programming the Order of Playback 12
■ Checking or Changing Programmed Tracks 13

♦ TUNER
■ Searching for and Storing the Radio Stations 13
■ Selecting a Stored Station 14
■ Improving Radio Reception 14

♦ TAPE DECK
■ Listening to a Cassette 15
■ CD Synchro Record Feature 15
■ Recording a Compact Disc 15
■ Recording a Radio Programme 16
■ Copying a Cassette (Dubbing) 16
■ Tape Counter 16
■ Selecting the Cassette Playback Mode(DECK 2 only MAX-S530) 16

♦ OTHER FUNCTIONS
■ Timer Function 17
■ Cancelling the Timer 18
■ Mute Function 18
■ Selecting an Equalizer Preset 18
■ Power Sound Function 18
■ Setting the System to Switch off Automatically 19
■ Super Bass Sound 19
■ Connecting Headphones 19
■ Microphone Function(OPTION) 19
■ Connecting to an External Source 20

♦ RECOMMENDATIONS FOR USE
■ Safety Precautions 20
■ Cleaning Your Mini-Compact System 21
■ Precautions When Using Compact Discs 21
■ Precautions When Using Audio Cassettes 21
■ Before Contacting the After-Sales Service 21
■ Technical Specifications 22

Symbols

Press

Push

Important

Note

Front Panel View

GB



1. Standby/On
2. Timer/Clock
3. Timer On/Off
4. AI Sleep
5. Headphone Jack Connector
6. Program
7. MIC Level
8. MIC
9. CD Repeat
10. Counter Reset(for MAX-S520)
    Reverse Mode(for MAX-S530 See P16)
11. Deck 1/2
12. Cassette Deck 1
13. Record/Pause
14. TAPE Normal Dubbing
15. CD Synchro Recording
16. Function Selection buttons
17. Cassette Deck 2
18. Skip Function buttons
19. Super Bass
20. Stop button
21. EQ Preset Lambada
22. EQ Preset Samba
23. EQ Preset Salsa
24. Enter
25. Search Function buttons
26. Volume
27. Power Sound
28. Compact Disc Compartment
29. CD Open/Close
30. Disc Change
31. Disc Selection buttons
32. Window VFD
33. Memory
34. Mono/Stereo
35. Demo/Dimmer

The picture of Front panel is based on MODEL:MAX-S520
MAX-S520 TAPE ▶
MAX-S530 TAPE ◀▶ (See P16)

Remote Control

GB



1. Standby/On
2. Super Bass
3. Latin Sound
4. TAPE Fast-Forward
5. TAPE Rewind
6. Demo
7. Deck 1/2
8. CD Repeat
9. CD Stop
10. Program/Set
11. CD Track or Radio Station Search(Skip)
12. FM Mono/stereo
13. Tuner Band
14. Volume Descrease
15. Tuning Mode(MANUAL,PRESET)
16. Volume Increase
17. Disc Skip
18. CD Play/Pause
19. CD Shuffle Play
20. Counter Reset
21. AI Sleep
22. TAPE Play
23. TAPE Stop
24. AUX
25. Timer On/Off
26. Mute

Rear Panel View

GB



1. **FM Aerial Connector Terminal**
2. **AM Aerial Connector Terminal**
3. **AUX-Input**
4. **Loudspeaker Connector Terminals**
5. **Voltage Selector(Option)**

Where to Install Your Mini-Compact System

To take full advantage of your new mini-compact system, follow these installation instructions before connecting the unit.

- Install the system on a flat, stable surface.
- Never place this unit on carpeting.
- Never place this unit in an outdoor area.
- Maintain an open space of approximately 6 inches (15 cm) on the sides and rear of the system, for ventilation purposes.
- Make sure that you have enough room to open the compact disc compartment easily.
- Place the loudspeakers at a reasonable distance on either side of the system to ensure good stereo sound.
- Direct the loudspeakers towards the listening area.
- For optimum performance, make sure that both speakers are placed at an equal distance above the floor.



Connecting the Loudspeakers

The loudspeaker connector terminals are located on the rear of the system.

There are four terminals on the system:

- Two for the left speaker (marked L)
- Two for the right speaker (marked R)

To achieve the correct sound quality, connect the:

- Red wire to the + terminals
- Black wire to the – terminals

1 **Press and hold the terminal tab.**

2 **Insert the speaker cord.**

3 **Release the finger.**



Inserting Remote Control Batteries

GB

Insert or replace remote control batteries when you:

- Purchase the mini-compact system
- Find that the remote control is no longer operating correctly

☛ When replacing the batteries, use a new set of batteries and never mix alkaline and manganese batteries.

1 Place your thumb on the position marked PRESS ▽ on the battery compartment cover (rear of the remote control) and push the cover in the direction of the arrow.

2 Insert two AAA, LR03 or equivalent batteries, taking care to respect the polarities:
   - + on the battery against + on the remote control
   - – on the battery against - on the remote control

3 Replace the cover by sliding it back until it clicks into position.



GB

Connecting the AM (MW/LW)Aerial

The AM aerial (for long and medium waves) can be:

- Placed on a stable surface
- Fixed to the wall (you must first remove the base)

The **AM** aerial connector terminals are located on the rear of the system and are marked **AM** .

To avoid noise interference, check that the loudspeaker wires do not run close to the aerial wires. Always keep them at least 2 inches (5 cm) away.



Connecting the FM Aerial

How to connect a COAXIAL TYPE aerial.

- Connect a 75Ω antenna to the **FM** antenna terminal.
- Plug the connector on the **FM** aerial supplied into the coaxial socket (75Ω) marked **FM** on the rear of the system.
- Follow the instructions given on Page 13 to tune into a radio station, and determine the best position for the aerial.
- If reception is poor, you may need to install an outdoor aerial.
  To do so, connect an outdoor **FM** aerial to the **FM** socket on the rear of the system using a 75Ω coaxial cable (not supplied).



GB

Connecting your System to the Power Supply

The main lead must be plugged into an appropriate socket.

☛ Before plugging your system into a main socket, you must check the voltage.

1 Check the position of the voltage selector on the rear of the system (OPTIONAL).

2 Plug the main lead (marked **AC Cord** on the rear of the system) into an appropriate socket.

3 Press the **On/Standby** button to switch your mini-compact system .



Demo/Dimmer function

All functions available on the system can be viewed on the display and the display's brightness can be switched between "on" and "off".

1 Press the **Demo/Dimmer** button.
Result: All functions available on the system appear on the front panel display.

➢ Each of these are explained in detail in this guide. Please refer to the relevant section.

2 Press the **Demo/Dimmer** button again.
Result: The Dimmer function is selected and the display darkens.

3 Press the **Demo/Dimmer** button once again to brighten the front panel display.

➢ A display brightness control can only be performed while the system power is on.



Setting the Clock

Your system is equipped with a clock which allows you to turn your system on and off automatically. You should set the clock:

- When you purchase the mini-compact system
- After a power failure
- After unplugging the unit

☛ ♦ For each step, you have a few seconds to set the required options. If you exceed this time, you must start again.

1 Switch the system on by pressing **Standby/on**.

2 Press **Timer/Clock** twice.
Result: **CLOCK** is displayed.

3 Press **Enter**.
Result: The hour flashes.

4

To...	Press the...
Increase the hours	Tuning Up
Decrease the hours	Tuning Down

5 When the correct hour is displayed, press **Enter**.
Result: The minutes flash.

6

To...	Press the...
Increase the minutes	Tuning Up
Decrease the minutes	Tuning Down

7 When the correct time is displayed, press **Enter**.
Result: The clock starts and is displayed, even when the system is in standby mode.

➢ ♦ You can display the time, even when you are using another function, by pressing Timer/Clock once.

♦ You can also use Program/Set button on the remote control to instead Enter button in step 3,5,7.



GB

Loading and Changing Compact Discs

The CD disc changer can contain up to three 12 cm or 8 cm compact discs without using an adapter.

☛ Never force the compact disc carrousel when opening and closing the compartment.

Never press down or place objects on the carrousel.

➢ Always treat your compact discs with care; refer, if necessary, to the section entitled "**Precautions When Using Compact Discs**" on page 20.

1 Switch the system on by pressing **Standby/on**.

2 Press the **Open/Close**(▲) button on the front panel.
Result: The compartment opens.

3 Place one or two discs in the front slots of the carrousel, with the label on the discs facing upwards.
☛ Check that the compact disc has been correctly inserted in the holder before closing the compartment.

4 If you wish to load a third compact disc, press the **Disc Change** button on the front panel (or **Disc Skip** on the remote control).
Result: The carrousel rotates by 120°.

5 Close the compartment by pressing the **Open/Close**(▲) button again.
➢ If you wish to start playing a disc directly, you can also proceed as follows.

To play...	Press...
Disc 1	CD (▶II) or Disc 1
Disc 2	Disc 2
Disc 3	Disc 3

Result: The compartment closes automatically and the disc selected starts playing.

6 To change or unload the compact disc changer, repeat Steps **2** to **5**.

☛ Keep the compartment closed whenever you are not using it, to prevent dust from entering.

➢ ♦ You can load or unload compact discs when the radio, tape or auxiliary source function is selected.



Listening to a Compact Disc

This unit has been designed to playback the CDs: Audio CD, CD Text, CD-R and CD-RW.
When you have loaded at least one compact disc into the player, you can start listening to it.
Continued use of irregular shape CDs (heart-shape, octagonal, etc.) can damage the unit.

1 Switch the system on by pressing **Standby/on**.

2 Select the CD function by pressing **CD** (▶II) .

3 Load one or more discs.

4 Press CD (▶II) on the front panel or ▶II on the remote control.

➢ If you have loaded more than one compact disc, they will be played in turn.

5 Adjust the volume as required by:
♦ Turning the **Volume** knob on the front panel
or
♦ Pressing the **VOL. +** or **-** buttons on the remote control

6 To pause temporarily during playback, press CD (▶II).

➢ Press **CD** (▶II) again to continue disc playback.

7 Press ■ when you have finished.

➢ ♦ When playing a disc, you can load new discs without stopping the current one. To do so, open the compartment by pressing Disc Change and load new discs in the other two vacant slots (not the one containing the disc that you are playing). You cannot rotate the carrousel during playback.
♦ When no discs are loaded, the **"NO DISC"** indication is displayed.
♦ The CD player stops automatically after playing the three discs, if the CD REPEAT function has not been selected.



When playing a CD-R or CD-RW
User-edited CD-Rs (Recordable)and CD-RWs (Rewritable) can be played back only if they are already "finalized".

♦ You can play back your original CD-Rs or CD-RWs recored in music CD format.(However,they may be played back depending on their characteristics or recording conditions.)
♦ Before playing back CD-Rs or CD-RWs, read their instructions or caution carefully.
♦ Some CD-Rs or CD-RWs may not be played back on this unit because of their disc characteristics, damage or stain on them,or if the player's lens is dirty.
♦ CD-RWs may require a longer readout time.(This is cause by the fact that reflectance of CD-RWs is lower than for regular CDs.)

GB

Selecting a CD in the Disc changer

The CD function is automatically selected when Disc Skip is pushed.

To select a specific disc, press the corresponding Disc (1, 2, 3) button on the front panel or Disc Skip on the remote control, until the required disc indicator flashes.
Result: All the discs will be played in turn, starting with the one selected.

➢ If you wish to play the current disc only, press CD Repeat on the front panel one or more times, until 1 CD is displayed.

➢
- If you use the Disc (1, 2, 3) function when listening to the radio or to a tape, the system switches automatically to the CD mode.
- If the disc selected is not loaded, the next disc is played automatically.



Selecting a Track

You can select the track you wish to listen to, either when the compact disc player is stopped or when a disc is playing.

To start playback at the beginning of the...	Press the ⏮ and ⏭ ...
Next track	Press ⏭ once
Current track	Press ⏮ once
Previous track	Press ⏮ twice
Track of your choice	The appropriate number of pressing the ⏮ and ⏭

.



Searching for a Specific Music Passage on a CD

When listening to a compact disc, you can quickly search for a specific music passage on a track.

➢ It is recommended that you turn the volume down before using this function.

To search through the tracks...	Press and hold down...
Forwards	⏭ for at least one second
Backwards	⏮ for at least one second

You can aslo press and hold down ◀◀ / ▶▶ on the front panel to auto search through the tracks.



Shuffle Play Function

You can listen to the tracks on a compact disc in a different order each time, as the various tracks will be selected automatically in a random sequence.

1 Press the **Shuffle** button.
Result: The **SHUFFLE** indication appears and all the tracks are played in a random order. Both the track number and the playing time are displayed.

2 When playing tracks in a random order, you can:
- Move on to the next track (selected at random) by pressing ⏮ /⏭
- Search quickly for a specific point in the current track by pressing ⏮ /⏭ more than one second.

3 When you have finished the random playback, press ■ or press the **Shuffle** button again.

➢ Repeat and CD Synchro function are not availabe in Shuffle playing mode.



GB

Repeating One or All Tracks on the Compact Discs

You can repeat indefinitely:

- A specific track on a compact disc.
- All tracks on the compact disc selected.
- All discs loaded in the carrousel

1

To repeat...	Press Repeat on the Front Panel one or more times until...
The current track indefinitely	**REPEAT 1** is displayed
The selected disc	**REPEAT 1 CD** is displayed
All discs loaded	**REPEAT ALL CD** is displayed

2 When you wish to stop the Repeat function, press **Repeat** until **ALL CD** or **1 CD** is displayed, or press ■ .



Programming the Order of Playback

You can decide:

- The order in which you listen to the tracks on the discs loaded
- Which tracks you do not wish to listen to

➢
- You can programme up to 24 tracks.
- You must stop the compact disc player before selecting the tracks.
- This feature can be combined with the Repeat function.

1 If the CD function is selected, stop the player by pressing ■ .

2 Load the selected CDs.

3 Press **Program**.
Result: The following indications are displayed:

PRGM 01 PR 01 -- --

(01 = Programme No, DI = Disc No, – – = Track No on the disc)

4 If necessary, select the disc containing the required track by pressing the corresponding **Disc (1, 2, 3)** button.

5 Select the required track by pressing the **Up** and **Down** button:
- Press ⏮ to move back through the tracks
- Press ⏭ to move forward through the tracks

6 Press **Program** to confirm your selection.
Result: The selection is stored and PRGM 02 PR 01 -- -- is displayed.

7 To select other tracks, repeat Steps **4** to **6**.

8 Press **CD** (⏯) to listen to the track selection in the order programmed.

9

To...	Press the ⏮ and ⏭ ...
Listen to the current track again	Press ⏮ once
Listen to the previous track	Press ⏮ twice
Listen to the next track	Press ⏭ once
Skip forwards or backwards one or more tracks	The appropriate number of pressing the ⏮ and ⏭

10 To cancel the selection, press ■ .
- Once if the compact disc player is stopped
  Result: **PRGM** is no longer displayed.

➢
- If you open the compartment, the selection is cancelled.
- If you select the number of a disc which is not loaded or a track which does not exist on the CD, the selection skips to the next programmed track.



Checking or Changing Programmed Tracks

You can check or change your selection of tracks at any time.

1 Press ■ once if you have started listening to the selection.

2 Press **Program**.
Result: The following indications appear: PROGRAM 01 CH DI – –
(CH = Check, 01=Program No, DI = Disc No, – – = Track No on the disc)

➢ If you have already programmed 24 tracks, **CH** is displayed instead of **PR** when you press **Program**.

3 Press **Program** again.
Result: The first track selected is displayed, together with the letter **CH**(Change).

4 Press **Program** one or more times until the track to be changed is displayed.

5 If necessary, press the corresponding **Disc (1, 2, 3**) button to change discs.

6 Press ⏮ / ⏭ to select a different track.

7 Press **Program** to confirm your change.

8 Press **CD** (⏯) to start listening to the selection.
Result: The first track selected is played.





Searching for and Storing the Radio Stations

GB

You can store up to:

- 15 FM stations or 15 FM stations
- 8 MW stations 15 AM stations
- 7 LW stations

1 Switch the system on by pressing **Standby/on**.

2 Select the TUNER function by pressing **TUNER** .

3 Select the required frequency band by pressing **TUNER (Band)** again on the front panel or **TUNER (Band)** on the remote control.
Result: The appropriate indication is displayed:

FM	Frequency Modulation
AM(MW)	Medium Wave
LW(Option)	Long Wave

4 Tune in to the desired station.

Manual tuning

- Press the **Tuning Mode** button so that the "**MANUAL**" indicator lights up on the front panel display.
- Press ◀◀ / ▶▶ on the main unit to tune in to the desired station manually.
  or
- Press **Tuning** ﹀ or ﹀ on the remote control to do the same.

Automatic tuning

- Press and hold ◀◀ / ▶▶ on the main unit for more than 1 second so that the "**AUTO**" indicator lights up on the front panel display.
- Press and briefly hold ◀◀ / ▶▶ on the main unit to begin automatic tuning.
  or
- Press and briefly hold **Tuning** ﹀ or ﹀ on the remote control to do the same.

- Use the manual tuning method if the automatic tuning search does not stop at the desired station because the signal is weak.

➢ For details on the Preset function, see the **"Selecting a Stored Station"** on page 16.

5 Adjust the volume by:
- Turning the **Volume** knob on the front panel
  or
- Pressing the **VOL. +** or **–** buttons on the remote control

6 Select the FM stereo or mono mode by pressing **Mono/ST.** on the remote control.





Searching for and Storing the Radio Stations (continued)

GB

7 If you do not want to store the radio station found, revert to Step 4 and search for another station.

Otherwise:

a Press **Memory**.
Result: The **PRGM** is displayed for a few seconds.

b Press **Tuning Down** and **Up** to assign a programme number between 1 and 15.

c Press **Memory** to store the radio station.
Result: **PRGM** is no longer displayed and the station is stored.

8 To store any other radio frequencies required, repeat Steps **3** to **7**.

➢ The PROGRAM function can be used to assign a new station to an existing programme number.



➢ In Tuner Mode

- In manual tuning mode, you can use ◀◀ / ▶▶ button to manual search a radio station.
- In manual tuning mode, you can press and hold down ◀◀ / ▶▶ button on the front panel or press and hold down **Tuning** ﹀ or ﹀ button on the remote control to auto search a radio station.
- During Tuner auto searching,press ◀◀ / ▶▶ or ■ button on the front panel to stop auto searching.
- In Preset tuning mode, you can use ⏮ / ⏭ button to search a stored radio station.
- you can use **Program /Set** button on the remote control to instead **Memory** button in step 7.

Selecting a Stored Station

You can listen to a stored radio station as follows:

1 Switch the system on by pressing **Standby/on**.

2 Select the TUNER function by pressing **TUNER** .

3 Select the required frequency band by pressing **TUNER** (Band) on the remote control or **TUNER** (Band) again on the front panel.

4 Press ⏮ / ⏭ button on the front panel of the unit, or the **Tuning Mode** button on the remote control until "**PRESET**" is displayed.

5 press ⏮ / ⏭ on the front panel of the unit to select the desired station.
or
Select the desired station by pressing the station number stored, using the **Tuning** ﹀ or ﹀ button on the remote control.
Result: The desired station is now received.



Improving Radio Reception

You can improve the quality of radio reception by:

- Rotating the FM or AM(MW) aerial
- Testing the positions of the FM and AM(MW) aerials before fixing them permanently

➢ If reception from a specific FM radio station is poor, press **Mono/ST.** on the remote control to switch from stereo mode to mono. The quality of the sound will be improved.



Listening to a Cassette

➢ ♦ Always treat your cassettes with care; refer, if necessary, to the section entitled "**Precautions When Using Audio Cassettes**" on page 21.

1 Switch the system on by pressing the **Standby/On** button.

2 Select the TAPE function by pressing **TAPE**.

3 Open either cassette deck 1 or 2 by pushing and releasing the deck cover where **Push Eject** (⏏) is written.

4 Insert the pre-recorded cassette with the open edge of the tape facing downward.

5 Close the deck by pushing on it until it clicks into place.
Result: Depending on the deck selected, the **1** or **2** indication is displayed in front of the counter number.

➢ If you insert a cassette in both decks, the system selects the deck in which you inserted the second cassette.

6 If you have inserted two cassettes, press **Deck 1/2** on the front panel or directly the **Deck 1/2** button on the remote control to select the cassette to be played.

Result: Depending on the deck selected, the TAPE 1 or TAPE 2 indication is displayed.

7 **FOR MAX-S520**

To listen to...	Press ...
Side A,B	TAPE (►)

Result: The cassette starts playing.

FOR MAX-S530

To listen to...	Press ...	
Side A	TAPE (◄►) once	DECK 1 and DECK 2
Side B	TAPE (◄►) twice	DECK 2 Only

Result: The cassette starts playing.

8 When the cassette is stopped, select one of the following functions as required.

To...	Press ...
Rewind the cassette	◄◄
Fast-forward the cassette	►►

9 When you have finished the function, press TAPE ■ on the remote control or ■ on the front panel to stop.



FOR MAX-S520



FOR MAX-S530

CD Synchro Record Feature

You can record a compact disc on a cassette in two different ways:
♦ Synchronised recording
♦ Direct recording
This feature enables you to synchronize the start of the recording with the start of the disc or track of your choice.

1 Switch the system on by pressing **Standby/On**.
2 Insert a blank cassette in Deck 2.
3 Select the CD function by pressing **CD** on the front panel.
4 Load a compact disc.
5 Select the required disc.
6 Select the required track and press **CD Synchro** or press **CD Synchro** directly to start recording at the beginning of the disc.
Result: **"REC" and "CD SYNC"** are displayed and recording starts.

7

To stop...	Press ...
Recording and playing the compact disc	■



Recording a Compact Disc

The direct recording mode enables you to start recording with any track on the compact disc.
♦ You can only record on cassettes in Deck 2.
♦ You do not need to adjust the volume, as it has no effect on the recording.

1 Switch your system on by pressing **Standby/On**.
2 Insert a blank cassette in Deck 2.
3 Select the CD function by pressing **CD** on the front panel.
4 Load the compact disc.
5 Select the required disc.
6 Select the required track on the compact disc and press ►II on the front panel or ►II on the remote control to set the compact disc player to Pause mode.
7 Press the **REC/Pause**.
Result: **REC** is displayed .
8 Press the ►II to start playing the track.
Result: The track is recorded on the cassette.
9 When you have finished recording, press TAPE ■ on the remote control or ■ on the front panel to stop recording.



GB

Recording a Radio Programme

You can record a radio programme of your choice.

- You can only record on cassettes in Deck 2.
- You do not need to adjust the volume, as it has no effect on the recording.

1 Switch the system on by pressing **Standby/On**.

2 Insert a blank cassette in Deck 2.

3 Select the TUNER function by pressing **TUNER** .

4 Select the radio station that you wish to record by pressing **Tuning** ^ or v on the remote control or by press the **Tuning Down** or **Up** on the front panel.

5 Press **REC/Pause**.
Result: **REC** is displayed in red and recording starts.

6 When you have finished recording, press the TAPE ■ on the remote control or ■ on the front panel to stop recording.



Copying a Cassette (Dubbing)

You can copy a cassette from Deck 1 to Deck 2.

- Normal speed dubbing

➢
- You do not need to adjust the volume, as it has no effect on the recording.
- Take care not to insert the tape to be copied in Deck 2, as it will be erased when you start recording.

1 Switch your system on by pressing **Standby/On**.

2 Insert a blank cassette in Deck 2.

3 Insert the tape to be copied in Deck 1.

4

To copy a cassette at...	Press...
Normal speed dubbing	Dubbing

Result: The appropriate indications are displayed and the cassette in Deck 1 is copied to the cassette in Deck 2.

5 Press ■ on the front panel or TAPE ■ on the remote control when you have finished recording.



Tape Counter

When playing a cassette, a counter is displayed to enable you to take note of the counter value at the start of each track and thus start playback at the beginning of the track to which you wish to listen.

➢ The counter is only displayed when a cassette is being played.

Before starting to record a cassette for which you wish to take note of the counter values at the beginning of each track, reset the counter by pressing **Counter Reset**.



Selecting the Cassette Playback Mode (Deck 2 Only MAX-S530)

Your mini-compact system has three cassette playback modes which enable you to listen to both sides of a cassette automatically.
Press REV. Mode until the appropriate symbol is displayed.

When the display indicates...	The mini-compact system plays back...
▶	One side of the selected cassette and then stops.
▶	One side of the cassette. The other side of the cassette and then stops.
⟲	Both sides of the cassette indefinitely until you press stop.



Timer Function

GB

The timer enables you to switch the system on or off at specific times.
Example: You wish to wake up to music every morning.

➢ If you no longer want the system to be switched on or off automatically, you must cancel the timer.

☛ ♦ Before setting the timer, check that the current time is correct.

♦ For each step, you have a few seconds to set the required options. If you exceed this time, you must start again.

1 Switch the system on by pressing **Standby/On**.

2 Press **Timer/Clock** until **TIMER** is displayed.

3 Press **Enter**.
Result: **ON TIME** is displayed (instead of the equalizer symbols) for a few seconds, followed by any switch-on time already set; you can set the timer switch-on time.

4 Set the timer switch-on time.

a Set the hour by pressing the ⏮ /⏭ buttons.

b Press **Enter**.
Result: The minutes flash.

c Set the minutes by pressing the ⏮ /⏭ buttons.

d Press **Enter**.
Result: **OFF TIME** is displayed (instead of the equalizer symbols) for a few seconds, followed by any switch-off time already set; you can now set the timer switch-off time.

5 Set the timer switch-off time.

a Set the hour by pressing the ⏮ /⏭ buttons.

b Press **Enter**.
Result: The minutes flash.

c Set the minutes by pressing the ⏮ /⏭ buttons.

d Press **Enter**.
Result: **VOL XX** is displayed, where **XX** corresponds to the volume already set.

6 Press **Skip Down** and **Up** to adjust the volume level and press **Enter**.
Result: The source to be selected is displayed.

7 pressing the ⏮ /⏭ buttons to select the source to be played when the system switches on .

If you select...	You must also...
TAPE (cassette)	Insert a recorded cassette in one of the decks before setting the system to standby.
TUNER (radio)	**a** Press **Enter**. **b** Select a preset station by pressing the ⏮ /⏭ buttons.
CD (compact disc)	**a** Load one or more compact discs. **b** Select the required disc.

8 Press **Enter** to confirm the timer.

9 Press **Standby/On** to set the system to standby mode.
Result: is displayed to the bottom left of the time, indicating that the timer has been set. The system will switch on and off automatically at the required times.

➢ If the timer switch on and off times are identical, the word **ERROR** is displayed.



➢ To set the timer function

♦ You can also use Program/Set button on the remote control to instead Enter button in step 3,4,5,6,7,8.

GB

Cancelling the Timer

After having set the timer, it will start automatically as shown by the TIMER indication on the display. If you no longer wish to use the timer, you must cancel it.

➢ You can stop the timer at any time (system on or in standby mode).

To...	Press Timer-On/Off...
Cancel the timer	Once. Result: is no longer displayed.
Restart the timer	Twice. Result: is displayed again.



Mute Function

You can turn the sound off temporarily on your system.
Example: You wish to answer a telephone call.

1 Press Mute.

2 To switch the sound back on (at the same volume as before), press **Mute** again or the **Volume** buttons.



Selecting an Equalizer Preset

Your mini-compact system is equipped with a preset equalizer that allows you to choose the most appropriate balance between treble and bass frequencies, according to the type of music you are listening to.

♦ Press EQ Preset (**Salsa/Samba/Lambada**) on the front panel or **Latin Sound** on the remote control until the required option is selected.

To obtain a...	Select...
Normal balance (linear)	PASS
Balance suitable for Salsa music	SALSA
Balance suitable for Samba music	SAMBA
Balance suitable for Lambada music	LAMBADA



Power Sound Function

Your mini-compact system is equipped with the function of Power Sound .
The function of Power Sound amplifies bass and improves high key or bass twice as much for you to appreciate powerful real sound.

➢ To select **Power Sound**

♦ Press **P.Sound** button on the front panel, "**P**,**SOUND**" is displayed.

♦ To cancel this function, press **P.Sound** button again .



GB

Setting the System to Switch off Automatically

While listening to a compact disc or a cassette, you can set the system to switch off automatically
Example: You wish to go to sleep to music.

1 Press **AI Sleep**.
Result: playback starts and the following indications are displayed:

90 MIN

2 Press **AI Sleep** one or more times to indicate how long the system should continue playing before it switches off:

(AI SLEEP) → 90 MIN → 60 MIN → 45 MIN → OFF → 15 MIN → 30 MIN →

➢ At any time, you can:
- ♦ Check the remaining time by pressing **AI Sleep**
- ♦ Change the remaining time by repeating Steps **1** and **2**

3 Press **AI Sleep** one or more times until **AI SLEEP** is displayed.
Result: The system will automatically switch off at the end of disc or cassette.

4 To cancel SLEEP or AI OFF function, press **AI Sleep** one or more times until **OFF** is displayed.



Super Bass Sound

Your mini-compact system has a bass amplification function called SBS (Super Bass Sound). This function makes the sound more powerful and real.

1 Press the **S.Bass** button on the front panel.
Result: **S. BASS** is displayed and "SBS ON" is displayed for a few seconds.

2 To cancel this function, press **S.Bass** again, "**OFF**" is displayed for a few seconds.



Connecting Headphones

You can connect a set of headphones to your mini-compact system so that you can listen to music or radio programmers without disturbing other people in the room. The earphones must have a 3.5 mm jack or an appropriate adapter.

Connect the headphones to the **Phones** jack on the front panel.
Result: The loudspeakers are no longer used to output the sound.

☛ Prolonged use of headphones at a high volume may damage your hearing.



Microphone Function (OPTION)

The microphone enables the user to mix in his or her vocals to sing-along with the music or recording .

Preparation
Plug the microphone with a 6.3mm mic jack into microphone terminal.

1 Turn the **MIC Level** knob to adjust the mic volume.



GB

Safety Precautions

The following diagrams illustrate the precautions to be taken when using or moving your mini-compact system.



Ambient operating conditions:
Ambient temperature 5°C-35°C
Humidity 10-75%



Do not expose the unit to direct sun radiation or other heat sources. This could lead to overheating and malfunction of the unit.



Do not place potted plants or vases on top of the unit. Moisture entering the unit could lead to dangerous electric shock and can cause equipment damage. In such events immediately disconnect the main plug from the socket.



During thunderstorms, disconnect the main plug from the socket. Main voltage peaks due to lightning could damage the unit.



Remove the batteries from the remote control, if not used for any extended periods.
Leaking batteries can cause serious damage to the remote control.



When using headphones, take care not to listen at excessive volumes. Extended use of headphones at high volumes will lead to hearing damage.



Do not place heavy items on the main lead. Main cable damage can lead to damage of the equipment (fire hazard) and can cause electric shock.



Do not remove any equipment panels. The inside of the unit contains live components, which cause electric shock.

Cleaning Your Mini-Compact System

To obtain the best possible results from your mini-compact system, you must clean the following elements regularly:

- The outer casing
- The compact disc player
- The cassette players (heads, rollers and drive capstans)

☛ Always unplug the system from the wall outlet:
- Before cleaning it
- If you are not going to be using it for a long time

Outer Casing

Clean the outer casing regularly using a soft cloth and a light detergent. Do not use abrasive powders, liquids or aerosol cleaners. Never let any liquids get into the system.

Compact Disc Player

1 Before playing a compact disc, clean it with a special CD cleaning agent. Do not use the same cleaning agents as for vinyl LP records. Carefully wipe the disc from the centre outward.

2 Regularly clean the player with a special cleaning disc (available from your local dealer).

Tape Decks

1 Press Push Eject (⏏) to open the cassette deck.

2 Use a cotton bud and a special cassette cleaning agent to clean the:
- Head (1)
- Rollers (2)
- Drive capstans (3)

☛
- If you will not be using the remote control for a long time, remove the batteries to prevent corrosion.
- Although your system is very hard-wearing, it should not be used in an excessively dusty environment or subjected to shocks or extreme heat (close to heating appliances or in direct sunlight, etc.).
- If the unit emits an unpleasant odor when in use, unplug it from the main supply and contact the after-sales service.



Precautions When Using Compact Discs

- Handle your compact discs with care. Always hold them by the edges to avoid leaving fingerprints on the shiny surface.
- When you have finished playing a compact disc, always put it back in its case.
- Do not fix paper or adhesive tape to the discs and do not write on the label.
- Clean them with a special-purpose cloth.
- Store your compact discs in a clean place, out of direct sunlight, where they will not be exposed to high temperatures.
- Always use compact discs marked .



GB

Precautions When Using Audio Cassettes

- Check that the tape in the cassette is sufficiently taught.
- To prevent erasing a cassette that you wish to keep, remove the safety tab on the upper edge of the cassette. To record a cassette, where the tab has been broken, simply cover the opening with adhesive tape.
- When you have finished playing a cassette, always put it back in its case.
- Store your cassettes in a clean place, out of direct sunlight, where they will not be exposed to high temperatures.
- Avoid using 120-minute cassettes as they place unnecessary strain on the tape mechanism.







Connecting to an External Source

The auxiliary input can be used to take advantage of the sound quality of your mini-compact system when listening to other sources.

Examples:
- A television
- A video disc player
- A DAT or DCC cassette player
- A Hi-Fi stereo video cassette recorder

➢ To connect the external source, the source must have an audio output. In addition, you need an RCA connection cable.

1 Set the system to standby mode and disconnect it and the external source from the main.

2 Connect the audio cable to the rear of the mini-compact system.

Connect the...	To the connector marked...
Red jack	R (right)
White jack	L (left)

➢ For optimum sound quality, do not invert the right and left channels.

3 Plug the system back into the main socket and press **Standby/On** to switch it on.

4 Select the AUX source by pressing **AUX** on the front panel.
Result: **AUX** is displayed.

5 Switch the external source on.

6 Adjust the volume and balance as required:
- Volume
- Equalizer

Example: You can watch a film and take advantage of stereo sound provided that the original sound track is in stereo, (as if you were in a cinema).





Before Contacting the After-Sales Service

It always takes a little time to become familiar with a new appliance. If you have any of the problems listed below, try the solutions given. They may save you the time and inconvenience of an unnecessary service call.

	Problem	Checks/Explanation
GENERAL	The system does not work	• *The main lead is not correctly plugged into a wall socket or the wall socket is not switched on.* • *The remote control batteries need replacing or the polarity has not been respected.* • *The Standby/On button has not been pressed.*
GENERAL	There is no sound	• *The volume has been completely turned down.* • *The correct function (TUNER, CD, TAPE, AUX) has not been selected.* • *You have connected a set of earphones.* • *The loudspeaker wires have been disconnected.* • *The MUTE button has been pressed.*
GENERAL	The Timer does not work	• *The timer has been stopped by pressing TIMER ON/OFF.*
GENERAL	System still doesn't work, even after following steps above.	• *Press the **S.Bass** button for 5 seconds in power 'OFF'(standby), the system is returned the original position (RESET)*
CD	The compact disc player does not start playing	• *The CD function has not been selected.* • *The disc has been inserted face down or is either dirty or scratched.* • *The laser sensor is dirty or dusty.* • *The system has not been installed on a flat, horizontal surface.* • *Condensation has formed in the player; leave the system in a warm, airy room for at least one hour.*
CASSETTES	The tape does not start playing	• *The TAPE function has not been selected.* • *The cassette has not been inserted correctly.* • *The cassette player has not been closed.* • *The tape is either slack or broken.*
CASSETTES	The volume falls off	• *The audio heads are dirty.* • *The rollers or drive capstans are dirty.* • *The tape is worn.*
RADIO	The cassette is not erased correctly There is excessive wow and flutter Reception is poor or no radio stations are received at all	• *The TUNER function has not been selected.* • *The radio frequency has not been correctly selected.* • *The aerial has been disconnected or is not facing the right way. Turn it until you find the best orientation.* • *You are in a building that blocks radio waves; you must use an outside aerial.*

If the above guidelines do not allow you to solve the problem, take a note of:
- The model and serial numbers, normally printed on the rear of the system
- Your warranty details
- A clear description of the problem

Then contact your local dealer or SAMSUNG after-sales service.

Technical Specifications

GB

SAMSUNG strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice.

RADIO	
LW**(option)**	
Usable sensitivity	60 dB
AM (MW)	
Signal/noise ratio	40 dB
Usable sensitivity	54 dB
Total harmonic distortion	2 %
FM	
Signal/noise ratio	62 dB
Usable sensitivity	10 dB
Total harmonic distortion	0.3 %
COMPACT DISC PLAYER	
Capacity	3 discs
Frequency range	20 Hz - 20 KHz (± 1 dB)
Signal/noise ratio	90 dB (at 1 KHz) with filter
Distortion	0.05 % (at 1 KHz)
Channel separation	74 dB
Disc sizes	Diameter: 120 or 80 mm. Thickness: 1.2 mm
TAPE DECK	
Frequency range	125 Hz ~ 8 KHz
Signal/noise ratio	40 dB
Channel separation	35 dB
Erasing effect	50 dB
AMPLIFIER	
Output power (6 Ω)	15 Watts / CH RMS, (total harmonic distortion: 10 %) (MAX-S520)
Output power (6 Ω)	35 Watts / CH RMS, (total harmonic distortion: 10 %) (MAX-S530)
Channel separation	45 dB
Signal/noise ratio	75 dB
GENERAL	
Dimensions	270 (W) x 317 (H) x 370 (D) mm

THIS APPLIANCE IS MANUFACTURED BY:

SAMSUNG ELECTRONICS

AH68-01228L